
Introduction to Morphological **Operators**

Introduction

- Structuring Element
- Erosion
- Dilation
- Opening
- Closing

Structuring Element (Kernel)

- Structuring Elements can have varying sizes
- Usually, element values are 0,1 and none(!)
- Structural Elements have an origin
- For thinning, other values are possible
- Empty spots in the Structuring Elements are don't



Examples of stucturing elements

Dilation & Erosion

- Basic operations
- Are dual to each other:
 - Erosion shrinks foreground, enlarges
 Background

Dilation enlarges foreground, shrinks background


Erosion


- **Erosion** is the set of all points in the image, where the structuring element "fits into".
- Consider each foreground pixel in the input image
 - If the structuring element fits in, write a "1" at the origin of the structuring element!
- Simple application of pattern matching
- Input:
 - Binary Image (Gray value)
 - Structuring Element, containing only 1s!

A first Example: Erosion

• Erosion is an important morphological

operation








Applied Structuring Element:


1	1	1
1	1	1
1	1	1


Set of coordinate points =





















Another example of erosion




• White = 0, black = 1, dual property, image $_{30-A}$ as a result of erosion gets darker


15

Erosion on Gray Value Images

• View gray value images as a stack of binary images!




Erosion on Gray Value Images





• Images get darker!

Counting Coins

- Counting coins is difficult because they touch each other!
- Solution: Binarization and Erosion separates them!









DILATION

Example: Dilation

• **Dilation** is an important morphological

operation





Applied Structuring Element:

1	1	1
1	1	1
1	1	1


Set of coordinate points =


Dilation


- **Dilation** is the set of all points in the image, where the structuring element "touches" the foreground.
- Consider each pixel in the input image
 - If the structuring element touches the foreground image, write a "1" at the origin of the structuring element!


• Input:


- Binary Image
- Structuring Element, containing only 1s!!






















Another Dilation Example




• Image get lighter, more uniform intensity

Dilation on Gray Value Images

 View gray value images as a stack of binary images!




Dilation on Gray Value Images





More uniform intensity

Edge Detection

- Edge Detection
- 1. Dilate input image
- 2. Subtract input image from dilated image
- 3. Edges remain!







Opening & Closing

- Important operations
- Derived from the fundamental operations
 - Dilatation
 - Erosion
- Usually applied to binary images, but gray value images are also possible
- Opening and closing are dual operations

OPENING

Opening


- Similar to Erosion
 - Spot and noise removal
 - Less destructive
- Erosion next dilation
- the same structuring element for both operations.
- Input:
 - Binary Image
 - Structuring Element, containing only 1s!

Opening

- Take the structuring element (SE) and slide it around *inside* each foreground region.
 - All pixels which can be covered by the SE with the SE being entirely within the foreground region will be preserved.
 - All foreground pixels which can *not* be reached by the structuring element without lapping over the edge of the foreground object will be eroded away!
- Opening is **idempotent:** Repeated application has no further effects!


Opening

• Structuring element: 3x3 square




Opening Example

• Opening with a 11 pixel diameter disc




Opening Example

• 3x9 and 9x3 Structuring Element




Opening on Gray Value Images

• 5x5 square structuring element



Use Opening for Separating Blobs

- Use large structuring element that fits into the big blobs
- Structuring Element: 11 pixel disc



CLOSING

Closing


- Similar to Dilation
 - Removal of holes
 - Tends to enlarge regions, shrink background
- Closing is defined as a Dilatation, followed by an Erosion using the same structuring element for both operations.
- Dilation next erosion!
- Input:
 - Binary Image
 - Structuring Element, containing only 1s!

Closing

- Take the structuring element (SE) and slide it around *outside* each foreground region.
 - All background pixels which can be covered by the SE with the SE being entirely within the background region will be preserved.
 - All background pixels which can *not* be reached by the structuring element without lapping over the edge of the foreground object will be turned into a foreground.
- Opening is **idempotent:** Repeated application has no further effects!


Closing

• Structuring element: 3x3 square



Closing Example


- Closing operation with a 22 pixel disc
- Closes small holes in the foreground




Closing Example 1

- 1. Threshold
- 2. Closing with disc of size 20








30-Apr-20

Thresholded


closed48

Closing Example 2

• Good for further processing: E.g. Skeleton operation looks better for closed image!




skeleton of Thresholded



skeleton of Thresholded and next closed 49

Closing Gray Value Images

• 5x5 square structuring element



Opening & Closing


- Opening is the *dual* of closing
- *i.e.* opening the foreground pixels with a particular structuring element
- is equivalent to closing the background pixels with the same element.

30-Apr-20 51


Examples

30-Apr-20 52


Example: blob separation/detection by erosion




Original binary image Circles (792x892)



Erosion by 30x30 structuring element




Erosion by 70x70 structuring element




Erosion by 96x96 structuring element


Example: blob separation/detection by erosion




Original binary image *Circles* (792x892)



Erosion by disk-shaped structuring element Diameter=15




Erosion by disk-shaped structuring element Diameter=35




Erosion by disk-shaped structuring element Diameter=48


Example: chain link fence hole detection



Original grayscale image Fence (1023 x 1173)




Fence thresholded using Otsu's method



Erosion with 151x151 "cross" structuring element

Small hole removal by closing




Original binary mask



Dilation 10x10




Closing 10x10



Difference to original mask

Morphological edge detectors



Morphological edge detector

